

## CLEANING AND PROTECTING INTRICON PRODUCTS

### GENERAL CLEANING

#### RECOMMENDED:

When cleaning headset, headworn and boom microphone, gently wipe the outside surfaces using a soft cloth moistened with water and mild soap.

#### ALTERNATIVE:

Alcohol content may damage the aesthetic of the mic. Use ultraviolet ray or antiseptic spray without alcohol content only.

#### DON'Ts:

1. Do not immerse product in water or any other liquid.
2. Do not use bleach or other alcohol content cleaning agents, i.e. solvents, alcohol, toluene, degreasing oil, pine perfume.

### MICROPHONE WINDSCREEN:

#### RECOMMENDED:

1. Replace windscreen regularly or when necessary.
2. Wash the windscreen with mild soap and water, rinse and air dry (Performance of the waterproof windscreen may be affected after washing).

#### ALTERNATIVE:

Use ultraviolet ray or antiseptic spray without alcohol content only.

#### DON'Ts:

1. Do not use bleach or any cleaning products when washing windscreen.
2. Do not share.

### DISCLAIMER:

While we are not virologists and will not be able to provide medically proven advice. Above is just a guideline on how to take care of our products and every user's safety.