



AF-03 LIGHTWEIGHT HEADSET



Features:

- Superb Noise Cancelling microphone performance for accurate voice capture
- Waterproof Microphone
- Microphone head design comes with effective windscreen retention feature
- Suitable for use in extreme cold conditions

The AF-03 is both lightweight and comfortable. Its waterproof microphone provides advanced clarity and noise cancellation performance for the most demanding headset applications, even in very cold temperatures.

Much consideration has been put into the physical design of the AF-03. The flexible boom arm enables the user to position the microphone for optimum voice pickup. Cable runs neatly to the front where it can be conveniently connected to a radio or any other devices. The headband is highly resistant to corrosion and is easy to clean. With our special windscreen retention feature, there is no fear to accidentally losing the windscreen.

Specifications:

Microphone	Style MH-08
Generating Element:	Electret Condenser
Polar Pattern:	Noise Canceling
Frequency Response:	100 Hz to 10 kHz
Sensitivity:	-42 dB re 1V/Pa (1/4" distance B&K 4227)
Output Impedance:	2 kohms
Bias Voltage:	2 Vdc to 12 Vdc
Current Drain:	100 uA
Loudspeaker	
Impedance:	150 ohms
Rated Power:	10 mW
General	
Standard Accessories:	Windscreen, Ear Cushion & Cable Clip